



If product needs repainted...

- 1.** Take a wire brush and remove any loose paint and surface oxidation (residue).
- 2.** Use a clean rag to wipe down and remove any loose dirt or residue.
- 3.** Use black exterior grade paint and apply to cleaned area.
- 4.** After the spray paint dries apply the antique finish.
(see steps below on how to apply the antique finish)

How to Apply Antique Finish

Materials Needed

- Any Standard Paint Brush
- 12" x 12" Piece of Scrap Cardboard

- 1.** Dip only 1/8" of your paintbrush into the antiquing paint.
- 2.** Rapidly stroke wet brush onto cardboard to remove 80% - 90% of the excess paint. (creating a dry brush)
- 3.** Lightly stroke the fixture with the paintbrush until you achieve the desired shade.