


## How To Apply Vinyl Address Numbers:


**Step 1** - Measure and position your vinyl numbers and secure with tape along the top.



**Step 2** - Lift up and carefully remove backing, leaving the vinyl and transfer tape.



**Step 3** - Lower the vinyl and transfer tape into place. Using squeegee or credit card, firmly rub from the center outward to apply the vinyl, pressing hard enough to remove any air bubbles.



**Step 4** - Slowly peel off transfer tape to reveal your address numbers.



1634 Latrobe-Derry Road • Loyalhanna, PA 15661 • Phone: (724) 537-4711 • Fax: (724) 537-9313  
[www.specialliteproducts.com](http://www.specialliteproducts.com) • [customer\\_service@specialliteproducts.com](mailto:customer_service@specialliteproducts.com)

Date: 05/07/2020  
Drawing Number: 23965-1

## How To Apply Self Adhesive Address Numbers:

**Step 1** - Measure and position your address numbers.



**Step 2** - One at a time, pick up each number and remove backing to reveal adhesive and place back onto mailbox or plaque.



**Step 3** - Firmly press each number down.



1634 Latrobe-Derry Road • Loyalhanna, PA 15661 • Phone: (724) 537-4711 • Fax: (724) 537-9313  
[www.specialliteproducts.com](http://www.specialliteproducts.com) • [customer\\_service@specialliteproducts.com](mailto:customer_service@specialliteproducts.com)

Date: 05/07/2020  
Drawing Number: 23964-1