

# Instructions for a WRB6

1 After Direct Burial Pole is secure in the cement footer, slide Base Section over pole and tighten Set Screws to secure Base to Pole.

